

## Typical Gel Times for DERA KANE 411 Resins Using MEKP

Temperature	10–20 minutes	20–40 minutes	40–60 minutes
Cool – 60s°F (15°-20°C)	1.25% MEKP 0.30% CoNap 0.20% DMA	1.25% MEKP 0.30% CoNap 0.05% DMA	1.25% MEKP 0.20% CoNap 0.03% DMA
Warm – 70s°F (21°-26°C)	1.50% MEKP 0.30% CoNap 0.05% DMA	1.50% MEKP 0.20% CoNap 0.05% DMA 0.05% 2, 4-P	1.25% MEKP 0.20% CoNap 0.05% DMA 0.075% 2, 4-P
Hot – 80s°F (27°-32°C)	1.25% MEKP 0.20% CoNap 0.05% DMA	1.00% MEKP 0.20% CoNap	1.25% MEKP 0.20% CoNap 0.10% 2, 4-P

Table information is not intended for use with 411-350 PA or 411-700 PAT.

Materials used with DERA KANE 411 series resins are 6% cobalt naphthenate (CoNap); 100% N, N-dimethylaniline (DMA); MEKP (9% active oxygen); and 100% 2, 4-pentanedione (2, 4-P).

Because of the reactive nature of these products, gel times can vary.

Always test gel times with a small amount of resin before formulating large quantities.

## Typical Gel Times for DERA KANE 411 Resins Using BPO and DMA

Temperature	10–20 minutes	20–40 minutes	40–60 minutes
Cool – 60s°F (15°-20°C)	2.00% BPO 0.20% DMA	1.50% BPO 0.15% DMA	1.50% BPO 0.10% DMA
Warm – 70s°F (21°-26°C)	1.50% BPO 0.15% DMA	1.00% BPO 0.10% DMA	1.00% BPO 0.05% DMA
Hot – 80s°F (27°-32°C)	1.00% BPO 0.10% DMA	1.00% BPO 0.05% DMA	0.75% BPO 0.05% DMA

Table information is not intended for use with 411-350 PA and 411-700 PAT.

Formulation was based on 98% active benzoyl peroxide (BPO); consequently, 2½ times as much of a 40% paste is required.

Because of the reactive nature of these products, gel times can vary.

Always test gel times with a small amount of resin before formulating large quantities.

## Typical Gel Times For DERA KANE 411 Resins Using BPO and DEA

Temperature	10–20 minutes	20–40 minutes	40–60 minutes
Cool – 60s°F (15°-20°C)	2.00% BPO 0.25% DEA	2.00% BPO 0.25% DEA 0.01% TBC	2.00% BPO 0.25% DEA 0.02% TBC
Warm – 70s°F (21°-26°C)	1.50% BPO 0.20% DEA	1.50% BPO 0.20% DEA 0.02% TBC	1.50% BPO 0.20% DEA 0.03% TBC
Hot – 80s°F (27°-32°C)	1.20% BPO 0.15% DEA	1.20% BPO 0.15% DEA 0.02% TBC	1.20% BPO 0.15% DEA 0.03% TBC

Table information is not intended for use with 411-350 PA and 411-700 PAT.

Formulation was based on 98% active benzoyl peroxide (BPO); consequently, 2½ times as much of a 40% paste is required.

Materials used with DERA KANE 411 series resins are 100% N, N-diethylaniline (DEA) and a 10% tert-butylcatechol (TBC) solution. Since formulation was based on 100% active TBC, 10 times as much of a 10% solution is required.

Because of the reactive nature of these products, gel times can vary.

Always test gel times with a small amount of resin before formulating large quantities.



Ashland is committed to the continuous evolution of technology and service solutions that promote health, safety and environmental protection around the world.

® Registered trademark and ™ trademark of Ashland Inc.

\* Registered service mark of the American Chemistry Council

© 2002, 2004 Ashland Inc. All Rights Reserved. • CWT-DS-344 Rev. 1

All statements, information and data presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, express warranty or implied warranty of merchantability or fitness for a particular purpose, or representation, express or implied, for which seller assumes legal responsibility, and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent.

## Using Trigonox 239A or CHP-5 Compounds As a Non-Foaming MEKP Substitute

Temperature	10–20 minutes	20–40 minutes	40–60 minutes
Cool – 60s°F (15°-20°C)	2.0% Catalyst* 0.5% CoNap 0.2% DMA	2.0% Catalyst 0.3% CoNap 0.1% DMA	2.0% Catalyst 0.4% CoNap 0.2% DMA 0.05% 2, 4-P
Warm – 70s°F (21°-26°C)	2.0% Catalyst 0.6% CoNap	2.0% Catalyst 0.3% CoNap	2.0% Catalyst 0.5% CoNap 0.05% 2, 4-P
Hot – 80s°F (27°-32°C)	1.5% Catalyst 0.4% CoNap	1.5% Catalyst 0.5% CoNap 0.05% 2, 4-P	1.5% Catalyst 0.4% CoNap 0.1% 2, 4-P

Materials used with DERAKANE 411 resins are 6% cobalt naphthenate (CoNap); 100% dimethylaniline, 100% Trigonox 239A and CHP-5, and 100% 2, 4-pentanedione (2, 4-P). Because of the reactive nature of these products, gel times can vary.

Always test gel times with a small amount of resin before formulating large quantities.

NOTE: When using 239A or CHP-5 to catalyze DERAKANE resins, peak exotherms are lowered, as compared to equivalent MEKP/CoNap catalyst systems.

DERAKANE 411-type resins may experience peak exotherm reductions up to 40° to 50°F (based on 50 g. mass).

\* Trigonox 239A or CHP-5.



Ashland is committed to the continuous evolution of technology and service solutions that promote health, safety and environmental protection around the world.

<sup>®</sup> Registered trademark and <sup>™</sup> trademark of Ashland Inc.

\* Registered service mark of the American Chemistry Council

© 2002, 2004 Ashland Inc. All Rights Reserved. • CWT-DS-344 Rev. 1

All statements, information and data presented herein are believed to be accurate and reliable but are not to be taken as a guarantee, express warranty or implied warranty of merchantability or fitness for a particular purpose, or representation, express or implied, for which seller assumes legal responsibility, and they are offered solely for your consideration, investigation and verification. Statements or suggestions concerning possible use of this product are made without representation or warranty that any such use is free of patent infringement and are not recommendations to infringe on any patent.